PHY4311 ASSIGNMENT 5

MOHAMMED CHAMMA 6379153 FEBRUARY 4TH 2015

You are given a CO_2 laser which will be used in a manufacturing plant to weld the frame of cars. You are told that the laser has a small signal gain of 3%/cm and a cavity with L=1m with one cavity mirror. The laser mirrors are as follows: one mirror has $(r_1, s_1, t_1) = (0.95, 0.1, 0.04)$ and the other has $(r_2, s_2, t_2) = (1.0, 0, 0)$. The saturation intensity you are told is $I_s = 100W/cm^2$.

Problem 1. Please calculate the output power per unit area of the laser

$$I^{out} = \frac{t}{2} I_{sat} \left(\frac{2g_0 \ell}{t+s} - 1 \right)$$

$$= \frac{0.04}{2} (100W/cm^2) \left(\frac{2(0.03cm^{-1})(100cm)}{0.04 + 0.01} - 1 \right)$$

$$= 238W/cm^2$$

Problem 2. How much power is deposited in the output window?

$$I^{window} = sI^{+} = \frac{s}{2}I_{sat}\left(\frac{2g_{0}\ell}{t+s} - 1\right)$$

$$= \frac{0.01}{2}(100W/cm^{2})\left(\frac{2(0.03cm^{-1})(100cm)}{0.04 + 0.01} - 1\right)$$

$$= 59.5W/cm^{2}$$

That's a lot!

Another way to get this is to notice $s = \frac{1}{4}t$ so

$$I^{window} = sI^+ = \frac{1}{4}tI^+ = \frac{1}{4}I^{out} = \frac{238}{4} = 59.5W/cm^2$$

Problem 3. Please compare the power deposited in the window with a reasonable estimate of that deposited in a window by a 100W lightbulb.

The 100W lightbulb gives about 10W of light power. If the window is a meter away the lightbulb deposits

$$P_L = \frac{10W}{4\pi(1m)^2} = \frac{10W}{4\pi(100cm)^2} = 7.96 \times 10^{-5} W/cm^2$$

Over a million times weaker than the laser!

Problem 4. For the laser just described, assume the loss is always 1%. Find the transmission coefficient for the mirror that will optimize the light output (highest power per unit area) and find this optimum output.

The optimal transmission coefficient is

$$t_{opt} = \sqrt{2g_0\ell s} - s$$

= $\sqrt{2(0.03cm^{-1})(100cm)(0.01)} - 0.01$
= 0.23

But we need to make sure that the gain at this transmission coefficient is larger than the small signal gain. This is equivalent to checking

$$g_0 > \frac{s}{2\ell}$$

 $0.03cm^{-1} > \frac{0.01}{2(100cm)}$
 $0.03cm^{-1} > 0.00005cm^{-1}$

and indeed it is. This means the laser can operate at the optimal transmission of t = 0.23.

The optimal output is

$$I_{max}^{out} = I_{sat}g_o\ell$$

= $100W/cm^2(0.03cm^{-1})(100cm)$
= $300W/cm^2$